



Z1231-D AND Z1236 TRUSS ROD ASSEMBLY INSTRUCTIONS

Dimensional Data (inches and [mm]) are Subject to Manufacturing Tolerances and Change Without Notice

The Z1231-D Concealed Arm Back-to-Back Carrier System and Z1236 Exposed Arm Carrier System are furnished as standard with a Truss Rod component that is intended to help secure and tie together the uprights within the system.

There are two methods that can be followed to attach and secure the Truss Rod to the carrier system (shown below). Either method is acceptable and should be followed when installing all applicable carrier systems.





- 1.) Check to make sure that the uprights are spaced apart at the correct rough-in dimension for the corresponding fixture that the carrier system will support.
- 2.) Locate the 3/8-diameter holes near the top of each upright and make sure that the uprights are positioned so that the holes are in line.
- 3.) Insert the truss rod through the two holes of the first upright and continue through the two holes of the second upright.
- 4.) Once the truss rod is in place, insert the two 1/4-20 x 3/4 set screws into the adjacent tappings on the uprights and tighten down the screws until the truss rod is firmly secured.

WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

⚠ADVERTENCIA: Cáncer y daño reproductivo - www.P65Warnings.ca.gov

AVERTISSEMENT: Cancer et effets néfastes sur la reproduction - www.P65Warnings.ca.gov

Zurn Industries, LLC | Specification Drainage Operation

1801 Pittsburgh Avenue, Erie, PA U.S.A. 16502 Ph. 855-663-9876, Fax 814-454-7929

In Canada | Zurn Industries Limited

www.zurn.com

3544 Nashua Drive, Mississauga, Ontario L4V 1L2 · Ph. 905-405-8272, Fax 905-405-1292

Α Date: 04/16/2018 C.N. No. 139851

Form No. C40

Rev.


Page 1 of 1



Z1231-D AND Z1236 TRUSS ROD ASSEMBLY INSTRUCTIONS

Dimensional Data (inches and [mm]) are Subject to Manufacturing Tolerances and Change Without Notice

If the hardware bag provided with the carrier system contains Truss Rod Clips, these clips can be used as part of an alternate method to secure the truss rod to the carrier (see below).



- 4.) Place a 3/8-diameter washer over the truss rod clip and proceed to place washers on all other remaining studs or U-bolts.
- 5.) Using the 3/8 jam nuts provided, thread the nuts onto the fasteners loosely..
- 6.) Insert the truss rod through the circular portion of each truss rod clip, ensuring that the uprights still remain in the correct positioning and spaced apart accordingly.
- 7.) Tighten down the jam nuts until the truss rod and header plates are firmly secured to the uprights.