




# Z886-HD


## INTO CATCH BASIN FABRICATION INSTRUCTIONS

Dimensional data (inches and [mm]) are subject to manufacturing tolerances and change without notice.

1. The cutout for the incoming trench can be made easily with a reciprocating saw as shown below.




2. Cut inlet adaptor to the correct depth and place as shown below. Drill 4 holes evenly spaced and thread screws through the adaptor into the catch basin.



3. Attach the incoming trench section with the hardware provided to complete the connection. Silicone adhesive may be used to keep debris from building up in the connection.

\*\*All catch basins to be installed with a minimum 4" [102mm] of concrete on all four sides and bottom.\*\*



**⚠ WARNING:** Cancer and Reproductive Harm - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

**⚠ ADVERTENCIA:** Cáncer y daño reproductivo - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

**⚠ AVERTISSEMENT:** Cancer et effets néfastes sur la reproduction - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)